



ASSEMBLY
JUMPERS

FROM	TO	COLOR
1	3	Red
2	6	Black
4	5	Red
5	7	Red
6	8	Black
3	4*	White

* Remove jumper from 3 to 4 in installations with switch.
In installation without switch use terminal pairs 5-6 and 7-8 for additional unswitched loads and do not use terminals 3 and 4.

ECC Distribution Box Switched Lighting

Order Number SC510-LDB

Electronic Control Concepts		
Title: LIGHTING_DIST_BOX		
Size A	Document Number	Rev A
Date: Tue, April 28, 2009		Sheet 1 of 1